



by John Perr
<johnperr(at)linuxfocus.org>

About the author:

Linux user since 1994; he is one of the French editors of LinuxFocus. Mechanical Engineer, MSc Sound and Vibration Studies

Basic acoustics and Signal Processing



Abstract:

This is Basic acoustics and Signal Processing for musicians and computer scientists.

If you ever dreamed of making your own recordings or fiddling around with sound on your computer, then this article is just for you.

Translated to English by:
John Perr
<johnperr(at)linuxfocus.org>

Introduction

This article intends to be educational. It hopes to provide the reader with a basic knowledge of sound and sound processing. Of course music is one of our concerns but all in all, it is just some noise among other less pleasant sounds.

First the physical concepts of sound are presented together with the way the human ear interprets them. Next, signals will be looked at, i.e. what sound becomes when it is recorded especially with modern digital devices like samplers or computers.

Last, up to date compressions techniques like mp3 or Ogg vorbis will be presented.

The topics discussed in this paper should be understandable by a large audience. The author tried hard to use "normal terminology" and particularly terminology known to musicians. A few mathematical formulas pop up here and there within images, but do not matter here (phew! what a relief...).


A bit of physics

Sound

Physically speaking, sound is the mechanical vibration of any gaseous, liquid or solid medium. The elastic property of the medium allows sound to propagate from the source as waves, exactly like circles made by a stone dropped in a lake.

Every time an object vibrates, a small proportion of its energy is lost in the surroundings as sound. Let us say it right now, sound does not propagate in a vacuum.

Figure 1a shows how a stylus connected to a vibrating source, like a speaker for example, converts to a wave when a band of paper moves under it.



*z: Vibrating stylus of amplitude $\pm A_0$
λ: wavelength
x: band speed at speed c
w: Resulting wave*

Figure 1a: Vibrating stylus on a moving paper band

As far as air is concerned, sound propagates as a pressure variation. A loudspeaker transmits pressure variations to the air around it. The compression (weak) propagates through the air. Please note that only the pressure front moves, not the air. For the circles in water mentioned earlier, waves do move whereas water stays in the same place. A floating object only moves up and down. This is why there is no "wind" in front of the loudspeaker. Sound waves propagate at about 344 meters per second, in air at 20°C, but air particles only move a few microns back and forth.




Figure 1b: vibrating piston in a fluid

Frequency and Pitch

We know now, from the above drawings, that sound waves have a sine shape. Distance between two crests is called wavelength and the number of crests an observer sees in one second is called frequency. This term used in physics is nothing but the pitch of a sound for a musician. Low frequencies yield bass tones whereas high frequencies yield high pitched tones.

Figure 2 gives values for both frequency and wavelength of sound waves propagating through the air:




Figure 2: Wavelength and frequency in the air

Amplitude and loudness

Another characteristic of sound is its amplitude. Sound can be soft or loud. Through the air it corresponds to small or large variation in pressure depending on the power used to compress air. Acousticians use decibels to rate the strength of sound. Decibel is a rather intricate unit as shown on drawings 3a and 3b. It has been chosen because figures are easy to handle and because this logarithmic formula corresponds to the behavior of the human ear as we shall see in the next chapter. Undoubtedly you are doing math without knowing it:

Power (Watt)	Level dB	Example	Power (W)
100 000 000	200	Saturn V Rocket	50 000 000
1 000 000	180		
10 000	160		
100	140	4 jet air liner	50 000
1	120	Large orchestra	10
0.01	100	Chipping hammer	1
0.000 1	80		
0.000 001	60	Shouted speech	0.001
0.000 000 01	40		
0.000 000 000 1	20	Conversational speech	20×10^{-6}
0.000 000 000 001	0		
0.000 000 000 000 1	0	Whisper	10^{-9}
0.000 000 000 000 001	0		

Sound power output of some typical sound sources

Sound amplitude can be measured in different ways. This also applies to other wave signals as Figure 5 demonstrate it:




Figure 5: Various measures of signal amplitude

Symbol	Name	Definition
A_{average}	Average Amplitude	Arithmetic average of positive signal
A_{RMS}	Root mean square	Amplitude proportional to energy content
A_{peak}	Peak Amplitude	Maximal positive amplitude
$A_{\text{peak-peak}}$	Amplitude peak to peak	Maximal positive to negative amplitude

The average amplitude is only a theoretical measure and technically not used. On the other hand, the root mean square value is universally adopted to measure equivalent signals and especially sine waves. For instance, the equivalent current available on one of your home plugs is rated 220 volts sinusoidal

varying at a constant frequency of 50 Hz. Here the 220 volts are RMS volts so that the voltage is really oscillating between -311 volts and +311 volts. Using the other definitions, this signal is 311 volts peak or 622 Volts peak to peak. The same definitions apply for the output of power amplifiers, fed to speakers. An amplifier able to yield 10 watts RMS will have a peak value of 14 watts and a peak to peak value of 28 watts. These peak to peak measurements of sine waves are called musical watts by audio-video retailers because the figures are good selling arguments.

Time and space

As it does with music, time plays a fundamental role with acoustics. A very close relationship binds time to space because sound is a wave that propagates into space over time.

Taking this into account, three classes of acoustic signals are defined:

- Periodic: Signals repeating over time
- Random : Signals not being periodic. In the following, we will deal with a restricted class of these signals; those having stable statistic properties over time. They are called random ergodic signals. This is the case for noises like white or pink noise used by scientists or some musicians.
- Pulse: Signals not repeating over time but with a defined shape.

The diagrams of figure 6 show some sound signals. We take advantage of these diagrams to introduce the notion of spectrum. The spectrum of a signal shows the different "notes" or pure sounds that make a complex sound. If we take a stable periodic signal like a siren or a whistle, the spectrum is stable over time and only shows one value (one line on figure 6a). This is because it is possible to consider each sound as the combination of pure sounds which are sine waves. We shall see later on that this decomposition of periodic signals into sine waves has been demonstrated by a French mathematician named Fourier in the 19th century. This will also allow us to talk about chords as far as music is concerned. Meanwhile, I shall stick to sine waves because it is a lot easier to draw than solos from Jimmy Hendrix.




Figure 6a: Pure sinusoid (simple and periodic)




Figure 6b: Combination of two sinusoids




Figure 6c: Square wave (complex but periodic)




Figure 6d: Random signal (complex and non periodic)

Figure 6: Sound signals and their spectra

In order to be able to process sound with a computer, we have to acquire it. This operation will allow us to transform the variation in pressure of the air into a series of numbers that computers understand. To do so, one uses a microphone which converts pressure variations into electrical signals and a sampler which convert the electric signal into numbers. A sampler is a general term and ADC (*Analog to Digital Converter*) is often used by electricians. This task is often devoted to the sound card of personal computers. The speed at which the sound card can record points (numbers) is called the sampling frequency. Figure 7 below shows the influence of the sampling frequency on a signal and its spectrum calculated by mean of the Fourier transform. Formula are here for the math addicts:




Figure 7a: Integral Transform.
Infinite and continuous in time and frequency domains




Figure 7b: Fourier Series.
Periodic in time and discrete in frequency domain




Figure 7c: Sampled Functions.
Discrete in time and periodic in frequency domain




Figure 7d: Discrete Fourier Transform.
Discrete and periodic both in time and frequency domains

This demonstrates (please believe me) that the transformation of a continuous wave into a series of discrete points makes the spectrum periodic. If the signal is also periodic, then the spectrum is also discrete (a series of points) and we only need to compute it at a finite number of frequencies. This is a good news because our computer can only compute numbers and not waves.

So we are now faced with the case of fig. 7d where a sound signal and its spectrum are both known as a series of points which where the fluctuate over time and in the frequency domain between 0 Hz and half the sampling frequency.

All these figures lining up have finally lost some part of the original sound signal. The computer only knows the sound at some precise moments. In order to be sure that it will be played properly and without any ambiguity, we have to be careful while sampling it. The first thing to do is to be sure that no frequency (pure sounds) greater than half the sampling frequency is present in the sampled signal. If not, they will be interpreted as lower frequencies and it will sound awful. This is shown in figure 8:




Figure 8a: Aliasing.

*Above: Sampling frequency equal to max. freq. and a DC signal as seen by the sampler.
 Below: Frequency component at the sampling frequency f_s is interpreted as DC*




Figure 8b: Aliasing.

Above: Frequency at $(1/N)f_s$

Below: Frequency component at $[(N+1)/N]f_s$ is interpreted as $(1/N)f_s$

This particular behavior of sampled signals is best known as the Shannon theorem. Shannon is the mathematician who has demonstrated this phenomenon. A similar effect can be observed on the cart wheels in films, e.g. westerns. They often appear to run backward because of the stroboscopic effect of films. For daily use of sound acquisition, this means that you need to eliminate all frequencies above half the sampling frequency. Not doing so will mangle the original sound with spurious sounds. Take for instance the sampling frequency of compact discs (44.1 KHz); sounds above 22 KHz must be absent (*tell your bats to keep quite because they chat with ultra sounds*).

In order to get rid of the unwanted frequencies, filters are used. Filter is a widely used term that applies to any device able to keep or transform partial sound. For example, low pass filters are used to suppress high frequencies which are not audible but annoying for sampling (*the gossiping of the bats*). Without going into details, the following diagram shows the characteristics of a filter:




Figure 9: Practical vs ideal filter.

I: Ideal filter

P: Practical filter

R: Ripple

B: Effective bandwidth

A filter is a device that changes the signal both the time and spectrum of the sound wave. A 100 Hz square wave low pass filtered at 200 Hz will become a sine wave because the upper part of its spectrum is removed (see figure 6c). Similarly, a note at 1000 Hz played by a piano (C 6) will sound like a whistle if it is filtered at 1200 or 1500 Hz. The lower frequency of the signal is called fundamental frequency. The others are multiples and are called harmonic frequencies. In the time domain, a filter introduces modifications of the wave called distortions. This is mainly because of the delay taken by each harmonic relatively to the others.

In order to show the influence of a filter on a signal, let us consider a simple square pulse (figure 10a), the amplitude of its spectrum (figure 10b) and the phase of its spectrum (figure 10c). This square pulse acts as a filter allowing sound to go through between $t=0$ and T seconds. The spectrum of the pulse represents the frequency response of the filter. We see that the higher the frequency of the signal, the bigger is the delay between the frequency components and the lower is their amplitude.




Figure 10a: Time signal. *Rectangular pulse at $t=0$.*




Figure 10b: Spectrum (Amplitude).




Figure 10c: Spectrum (Phase).

Figure 11 represents the influence of the rectangular filter on a simple signal like a sine wave.




Figure 11a: Rectangular pulse.
Impulsion at $t=0$.




Figure 11b: Sound pulse.


Cutting sound abruptly at time T introduces new frequencies in the spectrum of the sine wave. If the filtered signal is more complex, like the square wave of figure 6c, the frequency components will lag giving a distorted signal on the output of the filter.

Physico-acoustics

The human ear

For a better understanding of acoustics and sound, let us focus on the part we use to receive sound: the ear.


Figure 12 shows a cross section of the ear. Sound is collected in the pinna and channeled through the auditory canal toward the ear drum which acts more or less like a microphone. The vibrations of the ear drum are amplified by three small bones acting like levers and named the hammer, the anvil and the stirrup.



- a) Outer ear
- b) Middle ear
- c) Inner ear
- d) Pinna
- e) Ear Canal
- f) Ear Drum
- g) Stapes
- h) Malleus
- i) Incus
- j) Oval Window
- k) Round Window
- l) Eustachian Tube
- m) Scala Tympani
- n) Scala vestibuli
- o) Cochlea
- p) Nerve Fiber
- q) Semicircular canal

Figure 12: The main parts of the ear

The movements of the stirrup are transmitted via the oval window to the cochlea. The cochlea contains two chambers separated by the basilar membrane which is covered with sensitive hair cells linked to the auditory nerve (As shown on figure 13 and 14 below). The basilar membrane acts as spatial filter because the various parts of the cochlea are sensitive to the various frequencies thus allowing the brain to differentiate the pitch of notes.



- f) Ear Drum
 - g) Stirrup
 - h) Hammer
 - i) Anvil
 - j) Oval Window
 - k) Round Window
 - m) Scala Tympani
 - n) Scala vestibuli
 - r) Basilar Membrane
 - s) Helicotrema
-
- R) Relative response
 - F) Frequency response
 - D) Distance along membrane

Figure 13: Longitudinal section of the cochlea




Figure 14: Section across the cochlea

Perception

The brain plays a very important role because it does all the analysis work in order to recognize sounds, according to pitch of course, but also according to duration. The brain also performs the correlation between both ears in order to locate sound in space. It allows us to recognize a particular instrument or person and to locate them in space. It seems that most of the work done by the brain is learned. Figure 15 shows how we hear sounds according to frequencies.




Figure 15: Equal loudness contours

The curves above have been drawn for an average population and are a statistical result for people aged between 18 and 25 and for pure tones. The differences between individuals are explained by many factors among which:

- experience: being a musician or not for example.
- exposure to noise.
- age.

● ...

Figure 16 shows the influence of age on hearing loss for different frequencies. According to the sources the results are different. This is explained easily by the large variations that can be observed in a population and because these studies cannot easily take only age into account. It is not rare to find aged musicians with young ears as well as there are young people with important hearing loss due to long exposure to strong noises like those found in concerts or night clubs.




Figure 16: Age related hearing loss according to Spoor and Hinchcliffe

Noise induced hearing loss depends both on the duration of exposure and on the noise intensity. Note that all sounds are considered here as "noise" and not only the unpleasant ones. Thus, listening to loud music with headphones has the same effect on the auditory cells as listening to planes taking off on the end of the runway.

Figure 17 shows the effect of exposure to noise on hearing. Notice that the effects are not the same as those induced by age where the ear loses sensitivity at high frequencies. On the other hand, noise induced hearing loss makes the ear less sensitive around 3-4 KHz. At those frequencies, the ear is the most sensitive. This kind of hearing loss is usually seen among firearms users.




Figure 17: Development of noise induced hearing loss
Exp.: Years of exposure.

If you take a look at the chapter about decibels and their calculation, you will notice that about ten decibels corresponds to a very large acoustic pressure change. Having a linear decibel scale is equivalent to an exponential pressure scale. This is because the ear and the brain are able to handle very large variation of both amplitude and frequency. The highest frequency sound the healthy human can hear is 1000 times the frequency the lowest, and the loudest can have a sound pressure one billion times that of the quietest that can be heard (an intensity ratio of 10^{12} to 1).

Doubling pressure only represents 3 dB. This can be heard but an increase of 9 dB of the sound intensity is needed for the human being to have a subjective feeling of double volume. This is an acoustic pressure 8 times stronger!

In the frequency domain, changing octave is equivalent to doubling the sound frequency. Here too, we hear linearly the exponential increase of a physical phenomenon. Do not rush to your calculator yet, calculating the pitches of notes will be done later on.

Recording

Recording sound using an analog device like a tape recorder or a vinyl disc is still a common operation even if it tends to be overcome by digital systems. In both cases, transforming a sound wave into magnetic oscillations or digital data, introduces limits inherent to the recording device. We quickly talked earlier about the effects of sampling on the spectrum of sound. Other effects can be expected when recording sound:

Dynamic range

"Dynamic" is the term used for a recording device in order to express the difference between the minimum and maximum amplitude the device can record. It generally starts with the microphone, converting sound into an electrical signal, up to the recording medium, disc, tape or computer... Remember that decibels do express a ratio. As far as dynamic range is concerned, the value given is relative to the minimum of the scale which is 0 dB. Here are a few examples:

- Vinyl disc: 65 dB
- Magnetic tape: 55 dB
- 16 bits sampling (CD): 96 dB
- 8 bits sampling: 48 dB

A symphonic orchestra can play sounds ranging up to 110 dB. This is why disc editors use dynamic compression systems so that louder sounds are not clipped and quieter ones not lost into noise.

Ground noise

In addition to being less capable than the human ear, recording devices also have the drawback of generating their own noise. It can be the rubbing of the diamond on the vinyl disc or the snoring of the amplifier. This kind of noise is usually very low but do not allow for quietest sounds to be recorded. It is best heard most of the time with good quality headphones and sounds like a waterfall because it has a very wide spectrum including many frequencies.

Distortion

We saw earlier that filters have an important effect on the phase of a spectrum because they shift signals according to their frequency. This type of signal distortion is called harmonic distortion because it affects the harmonic frequencies of the signal.

Every single device recording a signal behaves like a filter and thus induces signal distortions. Of course, the same happens when you play any recorded sound again. Additional distortion and noise will be added.

Compression

More and more, compression algorithms like mp3 or Ogg Vorbis are used to gain precious disk space on our recording media.

These algorithms are said to be destructive because they do eliminate part of the signal in order to minimize space. Compression programs use a computer model of the human ear in order to eliminate the inaudible information. For instance, if two frequency components are close to each other, the quietest can be safely taken off because it will be masked by the louder one. This is why tests and advice can be found on the Internet in order to best use this software, i.e. keep the best part of the signal. According to those read by the author, most mp3 compressions do low pass filter sounds at 16 KHz and do not allow

for bit rates higher than 128 KiloBits/seconds. These figures are most of the time unable to maintain sound at CD quality.

On the other hand, compression software like gzip, bzip2, lha or zip do not alter data but have lower compression ratios. Moreover, it is necessary to uncompress the whole file before listening to it, which is not what is needed for a walkman or any other sound playing device.

What about music?

In order to settle things, here is a comparison of terms used by music and science. Most of the time, these comparisons have limits because the terms used by music lovers describe human hearing and not physical phenomenon.

Notes and pure frequencies

A note is defined, amongst others, by its pitch and this pitch can be assumed to be the fundamental frequency of the note. Knowing this, the frequencies of notes can be calculated with the following formula:

$$\text{FREQUENCY (in hertz)} = \text{REF} \times 2^{((\text{OCTAVE} - 4) + (\text{TONE} - 10) / 12)}$$

If we use **REF** for A at 440 Hz from octave 4 as base, we can compute the others for tones ranging from 1 to 12 from C to B:

Note	Octave							
	1	2	3	4	5	6	7	8
C	32,70	65,41	130,8	261,6	523,3	1047	2093	4186
C #	34,65	69,30	138,6	277,2	554,4	1109	2217	4435
D	36,71	73,42	146,8	293,7	587,3	1175	2349	4699
E b	38,89	77,78	155,6	311,1	622,3	1245	2489	4978
E	41,20	82,41	164,8	329,6	659,3	1319	2637	5274
F	43,65	87,31	174,6	349,2	698,5	1397	2794	5588
F #	46,25	92,50	185,0	370,0	740,0	1480	2960	5920
G	49,00	98,00	196,0	392,0	784,0	1568	3136	6272
A b	51,91	103,8	207,6	415,3	830,6	1661	3322	6645
A	55,00	110,0	220,0	440,0	880,0	1760	3520	7040
B b	58,27	116,5	233,1	466,2	932,3	1865	3729	7459
B	61,74	123,5	246,9	493,9	987,8	1976	3951	7902

The true music lovers will notice that we do not make any distinction between diatonic or chromatic half tones. With minimal changes, the same calculations can be done using commas as a subdivision instead of half tones...

Assuming notes are frequencies is far from being enough to distinguish a note played by one instrument from another one.. One also needs to take into account how the note is played (pizzicato or legato), from which instrument it comes, not counting all possible effects like glissando, vibrato, etc... For this purpose, notes can be studied using their sonogram which is their spectrum across time. A sonogram allows all the harmonic frequencies to be viewed along time.




Figure 18: A sonogram

T: Time A: Amplitude F: Frequency

Nowadays, electronic sound recording and playing uses totally artificial devices like synthesizers for creating sounds out of nothing or samplers to store sound and play it at different pitches with various effects. It is then possible to play a cello concerto replacing the instruments with sampled creaking of chairs. Every body can do it, no need to be able to play any instrument.

The characteristics of a single note are given in the diagram below:




Figure 19: Characteristics of a note: envelop

1: Attack A: Positive Amplitude
2: Sustain T: Time
3: Decay

The curve shows the evolution of the global loudness of sound along time. This type of curve is called an envelop because it does envelop the signal (grey part of the drawing). The rising part is called the attack and can differ tremendously according to the type of instrument. The second part is called sustain and is the body of the note and is often the longest part except for percussion instruments. The third part can also change shape and length according to the instrument.

Moreover, instruments allow musicians to influence each of the three parts. Hitting differently the keys of a piano will change the attack of the note whereas the pedals will change the decay. Each of the three parts can have its individual spectrum (color) which make the sound diversity infinite. Harmonic frequencies do not change at the same rate. Bass frequencies tend to last longer so that the color of the sound is not the same at the beginning and at the end of the note.

Range

According to its definition, the frequency range of a device can be associated to the range of an instrument. In both cases the terms describe a range of frequencies or pitches an instrument can play. However, the highest pitch an instrument can play is equivalent to the fundamental frequency given in the array above. In other words, recording a given instrument requires a device having a frequency range much higher to the highest note the instrument can play if the color of the notes are to be recorded. A short frequency range will low pass filter all the upper harmonics of the higher pitch notes and this will change sonority. In practice, a device with the frequency range of the human ear, i.e. 20hz to 20Khz, is needed. Often it is necessary to go higher than 20 KHz, because devices introduce distortion well before

the cut off frequency.

Harmonics and chords

Analysing the frequency array of notes above, musicians will find similarities between harmonic frequencies and notes making a chord.

Harmonic frequencies are multiples of the fundamental frequency. So for a C 1 at 32,7 Hz The harmonic frequencies are:

Harmonic	1	2	3	4	5	6	7	8
Frequency	32,7	65,4	98,1	130,8	163,5	196,2	228,9	261,6
Note	C	C	G	C	E	G	B b	C

Here we see why a chord is known as perfect (C-E-G-C) or seventh (C-E-G-Bb): The frequencies of the notes within the chord are aligned with the harmonic frequencies of the base note (C). This is where the magic is.

Conclusion

Without much going into the details, we have looked at the physical, human and technical aspects of sound and acoustics. This being said, your ear is will always be the best choice criterion. Figures given by mathematics or sophisticated measuring devices can help you understand why one particular record sounds weird but they will never tell you if the Beatles made better music than the Rolling Stones in the sixties.

Bibliography

Brüel & Kjaer: Danish company making measurement instruments for acoustics and vibrations. This company has published for a long time (fifty years or so) free books where most of the drawings for this article come from. These books are available on line in PDF format under the following <http://www.bksv.com/bksv/2148.htm> link.

<p>Webpages maintained by the LinuxFocus Editor team © John Perr "some rights reserved" see linuxfocus.org/license/ http://www.LinuxFocus.org</p>	<p>Translation information: fr --> -- : John Perr <johnperr@linuxfocus.org> fr --> en: John Perr <johnperr@linuxfocus.org></p>
--	--